



ARGUS/Process

Solve Your Process
Monitoring Tasks Efficiently

Features

- Continuous, reliable monitoring of industrial processes
- Spectroscopic measurement in gases and liquids
- Spectral range: UV, VIS, NIR
- Continuous data acquisition in the process stream by fiber optic probes and a process spectrometer
- Immediate interpretation of the measured data according to the analysis methods configured by the user
- Results are transmitted to master systems (system or process control) and displayed on screen
- Up to 8 points of measurement can be surveyed by one single software
- Calculation of colorimetric data
- Concentration determination by multi linear regression
- Determination of mass flows and integral mass of the observed substances
- Flexible measurement cycle programming with the possibility to control other devices
- Alarm generation by observation of spectra and calculated values
- Offline recalculation and spectra browsing
- File and printer logging